



furse Earth Bars

Part No.	Description
LK245-6	6 Way Earth Bar
LK245-8	8 Way Earth Bar
LK245-10	10 Way Earth Bar
LK245-12	12 Way Earth Bar
LK245-16	16 Way Earth Bar
LK245-20	20 Way Earth Bar


Other configurations available.



furse Earth Bars with Single Disconnecting Link

Part No.	Description
LK205	Disconnecting Link
LK243-6	6 Way Earth Bar c/w Disconnecting Link
LK243-8	8 Way Earth Bar c/w Disconnecting Link
LK243-10	10 Way Earth Bar c/w Disconnecting Link
LK243-12	12 Way Earth Bar c/w Disconnecting Link
LK243-16	16 Way Earth Bar c/w Disconnecting Link
LK243-20	20 Way Earth Bar c/w Disconnecting Link

Other configurations available.



furse Earth Bars with Twin Disconnecting Link

Part No.	Description
LK207-6	6 Way Earth Bar c/w Twin Disconnecting Link
LK207-8	8 Way Earth Bar c/w Twin Disconnecting Link
LK207-10	10 Way Earth Bar c/w Twin Disconnecting Link
LK207-12	12 Way Earth Bar c/w Twin Disconnecting Link
LK207-16	16 Way Earth Bar c/w Twin Disconnecting Link
LK207-20	20 Way Earth Bar c/w Twin Disconnecting Link

Other configurations available.



furse Insulator

Part No.	Description
IN005	Insulator with 2 Studs & 3 Nuts (M10)
IN013	Insulator Only

